

Index

Symbols

! command (Boot Monitor) 11-10

? command (Boot Monitor) 11-10

Numerics

3270 terminal emulation, configuration
parameters for 9-42

A

Acceleration Ratio (Change User
Preferences) 9-51

access control

configuration parameters for 9-9 to
9-13

font server 7-22

local clients, disabling 6-34

parallel port 15-10

serial ports 15-10

SNMP 16-3 to 16-7

terminal configuration data 6-30 to
6-34

XDM (X Display Manager) 8-15 to 8-16

see also passwords

Activate Alpha Buffer for RGBA Visuals
(Change User Preferences) 9-49

Add Domain to Unit Name as Filename
(Change Setup Parameters) 9-19

Add Timestamps (Change Setup
Parameters) 9-20

Additional Escape Chars (Change Setup
Parameters) 9-41

address discovery

addresses in NVRAM 3-11

BOOTP/DHCP 3-3 to 3-10

broadcast address 3-12

configuring in Boot Monitor
Setup 11-15

protocols

order of use 3-2

overview 3-1 to 3-2

RARP 3-10

subnet mask 3-13

address resolution 5-5

addresses, *see* Ethernet; IP (Internet
Protocol); Token-Ring

Administrative Contact (Change Setup
Parameters) 9-38

Administrative Status (Change Setup
Parameters) 9-38

Allow Alpha Test (Change User
Preferences) 9-48

Allow Blending (Change User
Preferences) 9-48

Allow Depth Test (Change User
Preferences) 9-48


Allow Dithering (Change User
Preferences) 9-48

Allow Exposures After Screen Saver
(Change User Preferences) 9-53

Allow Logical Operations (Change User
Preferences) 9-49

Allow MOP Reset (Change Setup
Parameters) 9-31

Allow Polygon Stipple (Change User
Preferences) 9-49




- Allow Scissor Test (Change User Preferences) 9-48
- Allow SNMP Reset (Change Setup Parameters) 9-11
- Allow Stencil Test (Change User Preferences) 9-48
- Allow XRemote TCP Connection (Change Setup Parameters) 9-41
- AppletViewer Command (Change Setup Parameters) 9-27
- apply** command (Configuration language) 6-34 to 6-37
- Arc Cache Maximum Size (Change Setup Parameters) 9-40
- arc caching, memory used for 9-40
- ARP (Address Resolution Protocol)
 - ARP cache 5-5 to 5-6
 - configuration parameters for 9-13
 - proxy ARP 5-29
- ARP Cache (Change Setup Parameters) 9-13
- Audio Enabled (Change Setup Parameters) 9-40
- Authorize XRemote Clients (Change Setup Parameters) 9-41
- Auto Save (Change Setup Parameters) 9-8
- Auto Save File (Change Setup Parameters) 9-20
- Auto Save File Name (Change Setup Parameters) 9-20
- Auto Save NVRAM (Change Setup Menus) 9-19
- Auto Saved Info (Change Setup Parameters) 9-20
- Automatic Lock Screen After (Change User Preferences) 9-46
- Automatic Logout After (Change User Preferences) 9-46
- Automatic Logout Cancel Delay (Change User Preferences) 9-46
- Automatically load images (Change Setup Parameters) 9-16

- Autorepeat Begin After (Change User Preferences) 9-47
- Autorepeat Rate (Change User Preferences) 9-48
- auto-save
 - configuring 6-34 to 6-37
 - disabling 6-35
 - extent of data saved 6-37
 - protocols for 6-35
 - saving parameters to a file 6-35 to 6-36
 - saving parameters to NVRAM 6-35

B

- backing store, configuring 9-54
- Backup File Server Address (Change Quick Setup) 9-4
- Backup File Service Protocol (Change Quick Setup) 9-4
- backward compatibility, parameters for 9-45
- bd** command (Boot Monitor) 11-7
- Be Compatible With Old DECwindows Images (Change User Preferences) 9-45
- Be Compatible With Old DECwindows Keyboards (Change User Preferences) 9-45
- Be Compatible With Old DECwindows Vendor String (Change User Preferences) 9-45
- Begin Sending Keepalives after (Change Setup Parameters) 9-30
- Bell Base Volume (Change User Preferences) 9-45
- Bell Duration (Change User Preferences) 9-45
- Bell Pitch (Change User Preferences) 9-45
- bell, configuration parameters for 9-45
- Bitmap Background Color (Change User Preferences) 9-53
- Bitmap File (Change User Preferences) 9-52




- Bitmap Foreground Color (Change User Preferences) 9-53
- bl** command (Boot Monitor) 11-7
- Black Pixel (Change Setup Parameters) 9-41
- bn** command (Boot Monitor) 11-7
- Boot automatically at power-up (Change Setup Parameters) 9-13
- Boot From (Change Quick Setup) 9-3
- boot host
 - backup hosts 4-16
 - first host to try 4-16
- Boot Host IP Address (Change Quick Setup) 9-3
- Boot Monitor
 - accessing 4-18, 11-6
 - booting from 4-17
 - commands 11-7 to 11-10
 - displaying 11-2
 - functions of 11-2 to 11-5
 - NVRAM utility
 - commands 11-20
 - sample sessions 11-21
 - starting 11-20
 - Setup
 - Boot window 11-16
 - exiting 11-17
 - keyboard type, setting 11-13
 - keymapper for 11-18
 - monitor dpi and resolution 11-13
 - navigating in 11-13
 - Network window 11-14 to 11-16
 - rebooting from 11-17
 - saving changes 11-17
 - starting 11-12
 - submenus 11-12
 - updating (Explora 400/450 and 700) 11-11
 - version, displaying 16-8
 - versions 11-1
- Boot Monitor Inverse Video (Change Setup Parameters) 9-14
- boot-automatically** 9-13, 11-7
- boot-custom-file** 9-14
- boot-default-server-when-prom-**
booting 9-14
- boot-desired-source** 4-8, 9-3, 9-14
- booting
 - absolute pathname requests 4-2, 4-6
 - automatic boot, disabling 4-4
 - boot hosts 4-16
 - booting sequence, default 2-1, 4-8
 - BOOTP/DHCP 3-3 to 3-10
 - broadcast requests, disabling 4-4
 - color database file, loading 2-5
 - configuration files, loading 6-21 to 6-27
 - configuration parameters for 9-3, 9-13 to 9-15
 - configuring in Boot Monitor Setup 11-16
 - default actions 2-1 to 2-5
 - from PCMCIA
 - manual boot 4-18
 - order of 4-8
 - manual
 - from PCMCIA 4-18
 - overview 4-17
 - using MOP 11-7
 - using NFS 4-18, 11-7
 - using TFTP 4-18, 11-8
 - modules, load policy 4-10
 - MOP requests
 - default 4-3
 - disabling 4-5
 - manual boot 11-7
 - order of 4-8
 - NFS requests
 - default 4-3
 - disabling 4-5
 - location of X servers 4-13
 - manual boot 4-18
 - order of 4-8
 - persistent, enabling 4-7

booting (continued)
 protocols
 backup choices 4-9
 first choice 4-9
 order of 4-2, 4-8 to 4-10
 RARP 3-10
 relative pathname requests 4-2, 4-6
 remote reset 16-10 to 16-13
 using *ncdreset* 16-11 to 16-12
 using *unit-administrative-status* 16-12
 reverse name request 3-15, 5-12
 TFTP requests
 default 4-2
 disabling 4-5
 location of X servers 4-12
 manual boot 4-18
 order of 4-8
 through a gateway 3-8 to 3-10, 11-7, 11-8
 X server loading 4-1 to 4-15
 see also address discovery; X server
boot-monitor-inverse-video 9-14
boot-mop 4-5, 9-15
boot-mop-with-file-name 9-15
boot-nfs-directory 9-15
BOOTP/DHCP
 /etc/*bootptab* file 3-5 to 3-10
 diagnostic messages 18-37
 enabling 3-4
 entry, example 3-7, 3-9
 option tags supported 3-6
bootpd (8)
 backup boot host, specifying 4-16
 enabling 3-4
boot-persistent-loading 9-14
boot-previous-server 9-14
boot-previous-source 9-14
boot-second-source 9-14
boot-send-broadcast-icmp-for-subnet-mask 3-14, 9-15
boot-tcpip-broadcast-boot-request 4-4, 9-15

boot-tcpip-desired-server 9-3, 9-14
boot-tcpip-product-name-and-memory-size-file 4-6, 9-15
boot-tcpip-product-name-and-memory-size-with-path-file 4-6, 9-15
boot-tcpip-product-name-file 4-6, 9-15
boot-tcpip-product-name-with-path-file 4-6, 9-15
boot-tcpip-second-server 9-14
boot-tcpip-third-server 9-14
boot-tcpip-unit-address-file 4-6, 9-15
boot-tcpip-unit-address-with-path-file 4-6, 9-15
boot-test-ram 9-13
boot-tftp-directory 9-15
boot-third-source 9-14
broadcast address 3-12
Broadcast Address (Change Setup Parameters) 9-25
Broadcast IP Address (Change Quick Setup) 9-5
Browser Module (Change Setup Parameters) 9-16
Browser Printer Table (Change Setup Parameters) 9-17
bt command (Boot Monitor) 11-8
Buffer Size (Change Setup Parameters) 9-20
Button Arrangement (Change User Preferences) 9-51
Button Press Threshold (Change User Preferences) 9-51
Button Release Threshold (Change User Preferences) 9-51

C

Cache Class File (Change Setup Parameters) 9-27
Cache Size Limit (Change Setup Parameters) 9-16
CALIBLIGHTPEN messages 18-15




- Calibrate Light Pen (Change Setup Parameters) 9-25
- Calibrate Touch Screen (Change Setup Parameters) 9-25
- CALIBTOUCH messages 18-16
- Change Quick Setup, *see* Setup menus (Console)
- Change Screen Saver After (Change User Preferences) 9-53
- Change Setup Parameters, *see* Setup menus (Console)
- Change User Preferences, *see* Setup menus (Console)
- Circuit Flush Timeout (Change Setup Parameters) 9-27
- Clear Messages command (Console) 18-4
- clients
 - font requests 7-4, 7-6
 - old X clients, error checks 9-45
 - X resources, loading 8-7
 - see also* local clients
- color
 - color text in Terminal Emulator 12-30
 - colormap, default 9-41
 - database file for 2-5, 5-15, 9-40
 - screen background 9-52, 9-53
 - with WinCenter 9-40
- Color Clipping Method (Change User Preferences) 9-50
- Command Menu (Change Setup Parameters) 9-18
- Complete Entry Timeout (minutes) (Change Setup Parameters) 9-13
- Config Access Control List (Change Setup Parameters) 9-10
- Config File (Change Quick Setup) 9-4
- config** file (font server) 7-23
- Config Read-Only Password (Change Setup Parameters) 9-9
- Config Read-Write Password (Change Setup Parameters) 9-9
- config-access-control-enabled** 6-30, 6-31, 9-10, 9-19
- config-access-control-list** 6-31, 9-10
- config-add-domain-to-unit-name-as-filename** 6-23, 9-20
- config-auto-saved-info** 6-37, 9-20
- config-auto-save-file** 6-36, 9-20
- config-auto-save-file-name** 6-36, 9-20
- config-auto-save-nvram** 6-35, 9-19
- config-custom-file** 6-23, 9-18
- CONFIGD messages 18-17
- config-default-file** 9-2, 9-4, 9-7, 9-8, 9-19, 9-44
- config-enforce-passwords-locally** 9-9
- config-generic-file** 6-24, 9-19
- config-load-initial-file** 6-27, 9-18
- config-ncdnet-object-name** 9-19
- config-persistent-loading** 6-22, 9-18
- config-pref-enforce-passwords-locally** 9-10
- config-pref-ncdnet-object-name** 9-20
- config-pref-read-only-password** 9-10
- config-pref-read-write-password** 9-10
- config-pref-tcp-port** 6-29, 9-20
- config-pref-telnet-port** 6-29, 9-20
- config-read-only-password** 9-8, 9-9, 9-43
- config-read-write-password** 9-8, 9-9, 9-43
- config-tcp-port** 6-28, 9-19
- config-telnet-port** 6-27, 6-28, 9-19
- config-unit-ethernet-address-file** 6-23, 9-19
- config-unit-ip-address-file** 6-24, 9-19
- config-unit-name-file** 6-23, 9-19
- config-unit-ncdnet-address-file** 6-24, 9-19
- config-unix-directory** 6-26, 9-4, 9-18
- Configuration daemon
 - configuration parameters for 9-19
 - defined 6-2
 - diagnostic messages 18-17
 - ports for accessing 6-28
 - starting from Terminal Emulator 12-2
- configuration file directory 6-26

- configuring terminals, *see* terminal
 - configuration; remote
 - configuration; remote
 - configuration files; Setup menus (Console); Setup (Boot Monitor); NVRAM utility
- config-use-decimal-ip-address-notation-as-filename** 6-24, 9-19
- config-vms-directory** 9-4, 9-18
- CONFUI messages 18-30
- Connect Timeout (Change Setup Parameters) 9-27, 9-31, 9-36
- Console
 - configuration parameters for 9-10, 9-46
 - diagnostic messages 18-33
 - disabling 6-34
 - key sequence for displaying 9-46
- Console Display Password (Change Setup Parameters) 9-10
- Console Key Sequence (Change User Preferences) 9-46
- CONSOLE messages 18-33
- CTERM
 - Terminal Host Chooser, automatic display of hosts 12-3
 - see also* Terminal Emulator
- Current Font Path (Change User Preferences) 9-47
- Current Pointing Device (Change User Preferences) 9-51
- Custom File (Change Setup Parameters)
 - remote configuration file 9-18
 - X server file 9-14


D

- da** command (Boot Monitor) 11-8
- Data Compression Mode (Change Setup Parameters) 9-41

- DECnet
 - configuration parameters for 9-31 to 9-32
 - statistics 10-9 to 10-11
- DECwindows
 - configuration parameters for 9-30, 9-45
- Default Colormap (Change Setup Parameters) 9-41
- Default File (Change Setup Parameters) 9-19
- Default Font Path at Reset (Change Quick Setup) 9-4
- Default for Enable X Access Control (Change Setup Parameters) 9-9
- Default home page (Change Setup Parameters) 9-16
- Default Hosts (Change Setup Parameters)
 - for 3270 Host Chooser 9-42
 - for Login Chooser 9-29
 - for login through the Terminal Emulator 9-39
- Default Linger Time (Change Setup Parameters) 9-36
- Default Packet Time-to-Live (Change Setup Parameters) 9-26
- Default Router (Change Setup Parameters) 9-31
- Default Server when PROM Booting (Change Setup Parameters) 9-14
- Default Visual (Change Setup Parameters) 9-41
- Default VMS File Name Extension (Change Setup Parameters) 9-23
- Delay LAT Display after Boot (Change Setup Parameters) 9-39
- Delay When Blanking Screen (Change User Preferences) 9-46
- DESKTOP messages 18-36
- DHCP
 - messages 18-37
 - see also* BOOTP/DHCP




- diag-access-control-enabled** 9-11
- diag-access-control-list** 9-11
- diag-add-timestamps** 9-20
- diag-buffer-size** 9-20, 18-6
- diag-log-file** 9-20, 18-5
- diag-ncdnet-object-name** 9-21
- Diagnostic Access Control List (Change Setup Parameters) 9-11
- Diagnostic daemon
 - configuration parameters for 9-20
 - messages about 18-38
 - starting from Terminal Emulator 12-2
 - TELNET connection to 18-4
- diagnostic messages, *see* messages
- diag-tcp-port** 9-20
- diag-telnet-port** 9-20
- diag-timestamp-frequency** 9-20, 18-5
- Disabled Commands (Change Setup Parameters) 9-18
- Disabled Networks (Change Setup Parameters) 9-29
- Disabled X Extensions (Change Setup Parameters) 9-40
- display background, configuration parameters for 9-52
- DISPLAY** environment variable
 - set by XDM 8-5
- Dither Flat Shaded Surface (Change User Preferences) 9-50
- Dither Interpolated Surface (Change User Preferences) 9-50
- dm** command (Boot Monitor) 11-8
- DNS (Domain Name System)
 - configuration parameters for 9-37
 - domain suffix, default 5-9
 - enabling 5-7
 - name server hosts, specifying 5-8
 - name space, widening searches of 9-37
 - reverse name request 3-15, 5-12
 - selecting 5-8
- DNS Default Domain (Change Setup Parameters) 9-37
- DNS Domain Search (Change Setup Parameters) 9-37
- documentation
 - conventions 1-5
 - how to comment on 1-6
 - intended audience 1-1
 - license server 1-4
 - NCDware manuals 1-4
 - WinCenter 1-5
- Domain Channel (Change Setup Parameters) 9-33
- DOS messages 18-38
- DPS (Display PostScript)
 - cache, freeing 13-12
 - CIE-dict19c.dat** file 13-7
 - configuration parameter for 9-21
 - file access protocols 13-3
 - fonts
 - adding 13-11
 - client access, configuring 13-11
 - directories 13-9
 - included in NCDware distribution 13-8
 - InitProc.dat** file 13-7
 - licensing 13-2
 - PSres.upr** file 13-3 to 13-6
 - resource path 13-10
 - Solaris systems, running applications on 13-13
 - support files 13-3 to 13-7, 13-10
 - terminals supported 13-1
 - troubleshooting 13-12
 - VM_3_2.SNF** file 13-7
- dps-resource-path** 9-21, 13-10
- dr** command (Boot Monitor) 11-8
- ds** command (Boot Monitor) 11-8
- DTR messages 18-40



E

- EHLLAPI A Default tcp Port (Change Setup Parameters) 9-42
- Enable 24-bit RGBA (Change User Preferences) 9-49
- Enable 3270 Terminal Emulation (Change Setup Parameters) 9-42
- Enable 8-bit Color-Index (Change User Preferences) 9-49
- Enable 8-bit RGBA (Change User Preferences) 9-49
- Enable Bell (Change User Preferences) 9-45
- Enable Benchmark Optimizations (Change User Preferences) 9-54
- Enable Config Access Control (Change Setup Parameters) 9-10
- Enable Diagnostic Access Control (Change Setup Parameters) 9-11
- Enable Execution Host Access Control (Change Setup Parameters) 9-12
- Enable Execution User Access Control (Change Setup Parameters) 9-12
- Enable File Manager Access Control List (Change Setup Parameters) 9-12
- Enable Floppy Filesystem (Change Setup Parameters) 9-23
- Enable Graphics Optimizations (Change User Preferences) 9-54
- Enable Keyboard Autorepeat (Change User Preferences) 9-47
- Enable NFS Server (Change Setup Parameters) 9-23
- Enable Screen Saver (Change User Preferences) 9-53
- Enable Serial and Parallel Access Control (Change Setup Parameters) 9-13
- Enable SNMP Read-Only Access Control (Change Setup Parameters) 9-11
- Enable SNMP Read-Write Access Control (Change Setup Parameters) 9-11
- Enable VESA Monitor Power Management 9-52
- Enable X Access Control (Change Setup Parameters) 9-9
- enet-interfaces-table** 10-2
- Enforce Config Passwords Locally (Change Setup Parameters) 9-9
- Enforce Console Password Locally (Change Setup Parameters) 9-10
- Enforce User Preferences Passwords Locally (Change Setup Parameters) 9-10
- Environment Variables (Change Setup Parameters), for the NCD Mosaic Browser 9-16
- Environment Variables (Change User Preferences), for local clients 9-47
- Equivalent IP Addresses (Change Setup Parameters) 9-26
- /etc/bootptab** file 3-5 to 3-10
- /etc/bootptab.cfg** file 3-3
- /etc/ethers** file 3-11
- /etc/services** file 3-4
- Ethernet
 - address
 - displaying 3-11
 - on terminal base 3-11
 - restoring 11-21 to 11-22
 - interfaces
 - configuration parameters for 9-32
 - statistics 10-13
- ex** command (Boot Monitor) 11-8
- exec-access-control-enabled** 9-12
- exec-access-control-list** 9-12
- exec-command-menu** 9-18
- EXECD messages 18-40
- exec-disabled-commands** 6-34, 9-18
- exec-startup-commands** 9-6, 9-18
- exec-user-access-control** 9-12
- Execution Access Control List (Change Setup Parameters) 9-12



Export Directory List (Change Setup Parameters) 9-23
 Extended Diagnostics (Change Setup Parameters) 9-22
 Extended File Diagnostics (Change Quick Setup) 9-4
 Extended Routing Diagnostics (Change Setup Parameters) 9-26


F

Failed Server Ignore Timeout (Change Setup Parameters) 9-22
 Fast MPEG decoder (Change Setup Parameters) 9-39
 Fast Perspective Rendering (Change User Preferences) 9-49
 File Manager Access Control List (Change Setup Parameters) 9-12
 File Server Address (Change Quick Setup) 9-3
 file service
 configuration parameters for 9-3, 9-22
 diagnostic messages 18-87
 diagnostic messages, extended 5-24
 file server hosts 5-13 to 5-20
 boot host 5-13
 in file service table 5-15
 initial file servers 5-13
 file service table 5-15 to 5-20
 locations of files, default 5-15
 matching filenames to file service table entries 5-18 to 5-20
 NFS
 configuring 5-22 to 5-23
 statistics 10-13
 TFTP
 configuring 5-20 to 5-22
 statistics 10-25
 timeouts, configuring 5-24
 File Service Protocol (Change Quick Setup) 9-3

File Service Table (Change Setup Parameters) 9-22
 FILED messages 18-44
file-default-vms-file-name-extension 9-23
file-enable-floppy-filesystem 9-23
file-enable-nfs-server 9-23
file-export-directory-list 9-23
file-extended-diagnostics 5-24, 9-4, 9-22, 13-12, 18-6
file-failed-server-ignore-timeout 5-24, 9-22
file-initial-protocol-1 9-3, 9-22
file-initial-protocol-2 9-4, 9-22
file-initial-server-1 9-3, 9-22
file-initial-server-2 9-4, 9-22
file-manager-access-control-enabled 9-12
file-manager-access-control-list 9-12
file-manager-ncdnet-object-name 9-21
file-manager-password 9-12
file-manager-tcp-port 9-21
file-manager-telnet-port 9-21
file-name-type-for-initial-tftp-servers 9-4, 9-22
file-nfs-access-control list 9-12
file-nfs-access-control-default 9-12
file-nfs-gid 5-23
file-nfs-uid 5-23
file-nfs-unmount-timeout 5-23, 9-22
file-service-table 5-16, 9-22
file-try-all-matches-on-open 5-19, 9-22
 floppy drive, diagnostic messages 18-38
 FONT messages 18-48
 Font Name Table (Change Setup Parameters) 9-24
 font server
 access control for 7-22
 architecture (illustration) 7-20
 backup font servers 7-21
 bitmap font format 7-21
 Bitstream Speedo outline fonts 7-21
 compressed font files 7-21
 configuration file, example 7-23
 configuration parameters for 9-24

- font server (continued)
 - defined 7-19 to 7-20
 - diagnostic messages
 - explanations of 18-48
 - displaying fonts 7-27
 - error logging 7-23
 - font formats 7-20 to 7-21
 - host load, configuring 7-22
 - IBM Type 1 (Adobe) outline fonts 7-21
 - installation 7-22
 - listing fonts 7-27
 - ncdfsinfo(1)** 7-26
 - ncdfsfonts** 7-27
 - outline fonts 7-20, 7-21
 - point size, default 7-23
 - resolution, default 7-23
 - SNF fonts 7-21
 - timeouts, configuring 7-25 to 7-26
- font-cache-hits** 10-3
- font-cache-size** 10-3
- font-cache-used** 10-3
- font-extended-diagnostics** 18-6
- font-number-of-fonts-in-cache** 10-3
- font-object-count** 10-3
- font-objects-currently-in-use** 10-3
- fonts
 - access sequence 7-2
 - available fonts, listing 7-18
 - BDF format
 - converting to PCF 7-10
 - defined 7-7
 - built-in 7-11
 - cache 7-14
 - characters in a font, displaying 7-18
 - client font requests 7-4, 7-6
 - configuration parameters for 9-4, 9-23, 9-47
 - default font 7-13
 - diagnostic messages
 - displaying 7-17
 - explanations of 18-48
 - logging 7-17

- fonts (continued)
 - directories for 7-8
 - downloading, protocols for 7-6
 - DPS fonts 13-8, 13-11
 - DWF format 7-7
 - files 7-8 to 7-10
 - font information, displaying 7-17 to 7-19
 - font names 7-2 to 7-5
 - font path
 - aliases for, creating 7-16
 - current 7-11 to 7-13
 - defined 7-6
 - displaying 7-18
 - xset(1)**, setting current font path 7-13
 - fonts.alias** file
 - defined 7-9
 - name, changing 7-15
 - fonts.dir** file
 - creating 7-10
 - defined 7-9
 - name, changing 7-15
 - formats 7-7
 - initial file server hosts 5-13
 - NCDware distribution, fonts
 - included 7-8
 - outline fonts
 - see* font server
 - PCF fonts 7-7
 - PEX fonts 14-2
 - samples of a font, displaying 7-19
 - SNF format 7-7
 - statistics 10-3
 - XLFD (X Logical Font Description) 7-2, 7-19
 - see also* font server
 - fonts.alias** file 7-9 to 7-10, 7-15
 - fonts.dir** file 7-9, 7-10, 7-15
 - font-total-fonts-loaded** 10-3
- FTP Proxy Overrides (Change Setup Parameters) 9-17



FTP Proxy Host (Change Setup Parameters) 9-17
 FTP Proxy Host Port (Change Setup Parameters) 9-17
 Function Key Style (Change User Preferences) 9-47

G

gateway
 booting through 3-8, 11-7, 11-8
 configuration parameters for 9-25
 default gateways 5-25
 router discovery 5-30
 see also routing
 Gateway IP Address (Change Quick Setup) 9-5
 get-protect command (Configuration language) 6-32, 6-33
 GET-PROTECTED parameter value 6-5
 Gopher Proxy Host (Change Setup Parameters) 9-17
 Gopher Proxy Host Port (Change Setup Parameters) 9-17
 Gopher Proxy Overrides (Change Setup Parameters) 9-17
 graphics optimizations, configuration parameters for 9-54

H

Hello Timeout (Change Setup Parameters) 9-31
 hostnames
 name service 5-7 to 5-10
 terminal
 configuration parameters for 9-38
 reverse name request 3-15, 5-12
 HTTP Proxy Host (Change Setup Parameters) 9-16
 HTTP Proxy Host Port (Change Setup Parameters) 9-16
 HTTP Proxy Overrides (Change Setup Parameters) 9-17

I


ICMP (Internet Control Message Protocol)
 configuration parameters for 9-26
 router discovery 5-30
 statistics 10-3 to 10-5
 subnet mask discovery 3-14
 icmp-address-mask-replies-received 10-4
 icmp-address-mask-replies-transmitted 10-5
 icmp-address-mask-requests-received 10-4
 icmp-address-mask-requests-transmitted 10-5
 icmp-destination-unreachables-received 10-3
 icmp-destination-unreachables-transmitted 10-5
 icmp-echo-replies-received 10-4
 icmp-echo-replies-transmitted 10-5
 icmp-echo-requests-received 10-4
 icmp-echo-requests-transmitted 10-5
 icmp-packets-received 10-3
 icmp-packets-received-with-errors 10-3
 icmp-packets-transmitted 10-4
 icmp-packets-unable-to-be-transmitted 10-4
 icmp-parameter-problems-received 10-4
 icmp-parameter-problems-transmitted 10-5
 icmp-redirects-received 10-4
 icmp-redirects-transmitted 10-5
 icmp-source-quenches-received 10-4
 icmp-source-quenches-transmitted 10-5
 icmp-time-exceededs-received 10-4
 icmp-time-exceededs-transmitted 10-5
 icmp-timestamp-replies-received 10-4
 icmp-timestamp-replies-transmitted 10-5
 icmp-timestamp-requests-transmitted 10-5
 icmp-timestamps-requests-received 10-4
 IEN 116 name service
 configuration parameters for 9-37
 enabling 5-7
 name server hosts, specifying 5-8
 selecting 5-8

Ignore Case on TCP/IP Name Cache Lookups (Change Setup Parameters) 9-37
Incomplete Entry Timeout (minutes) (Change Setup Parameters) 9-13
Initial Default Gateway 1 (Change Setup Parameters) 9-25
Initial Default Gateway 2 (Change Setup Parameters) 9-26
Initial File Server 1 (Change Setup Parameters) 9-22
Initial File Server 2 (Change Setup Parameters) 9-22
initial file servers, *see* file service
Initial Protocol 1 (Change Setup Parameters) 9-22
Initial Protocol 2 (Change Setup Parameters) 9-22
Input Extension Device (Change Setup Parameters) 9-25
IP (Internet Protocol)
 addresses
 configuration parameters for 9-25
 hexadecimal, converting to 4-15
 multi-homed hosts 3-15
 see also address discovery
 routing table 5-26 to 5-29
 statistics 10-6 to 10-8
IP Address (Change Setup Parameters) 9-25
IP Address At Next Boot (Change Setup Parameters) 9-25
ip-address 9-25
ip-address-at-next-boot 9-5, 9-25
ip-broadcast-address 3-12, 3-13, 9-5, 9-25
ip-default-packet-time-to-live 9-26
ip-equivalent-address 3-15
ip-equivalent-addresses 9-26
ip-extended-routing-diagnostics 9-26, 18-6, 18-55
ip-forwarding-type 10-6
ip-initial-default-gateway-1 5-25, 9-5, 9-25

ip-initial-default-gateway-2 5-25, 9-26
ip-packet-fragmentations-completed 10-8
ip-packet-fragmentations-not-completed 10-8
ip-packet-fragments-created 10-8
ip-packet-reassemblies-completed 10-8
ip-packet-reassemblies-not-completed 10-8
ip-packet-reassemblies-required 10-8
ip-packet-reassembly-timeout 10-7
ip-packets-forwarded 10-6
ip-packets-received 10-6
ip-packets-received-and-delivered 10-7
ip-packets-received-and-discarded 10-7
ip-packets-received-with-errors-in-ip-header 10-6
ip-packets-received-with-incorrect-address 10-6
ip-packets-received-with-unknown-protocols 10-6
ip-packet-transmission-requests 10-7
ip-packet-transmission-requests-discarded 10-7
ip-packet-transmission-requests-without-routes 10-7
ip-respond-to-broadcast-icmp 9-26
IPROUTE messages 18-55
ip-routing-table 5-27
ip-routing-table 5-27, 9-26
ip-subnet-mask 9-5, 9-25, 10-8
ip-use-address-discovery 9-26
ip-use-proxy-arp 5-30, 9-26
ip-use-router-discovery 5-30, 9-26
ip-use-router-solicit 5-30, 9-26

J

Java
 configuration parameters for 9-27
 diagnostic messages 18-36, 18-57
Java applets (Change Setup Parameters) 9-16
Java Directory (Change Setup Parameters) 9-27



JAVA messages 18-57
java-appletviewer-command 9-27
java-cache-class-file 9-27
java-directory 9-27
 Jscript/Javascript routines (Change Setup Parameters) 9-16


K

KBM messages 18-58
 Keepalive Idle Time (Change Setup Parameters) 9-36
 Keepalive Interval (Change Setup Parameters) 9-36
 Keepalive Timeout (Change Setup Parameters) 9-27, 9-31
 Keyboard Description File (Change Setup Parameters) 9-24
 Keyboard Type (Change Setup Parameters) 9-24
 keyboards
 compose sequences for Terminal Emulator 12-44 to 12-50
 configuration parameters for 9-24, 9-47
 dead-key processing 17-60 to 17-61
 downloadable keyboard description files
 creating 17-54 to 17-61
 diagnostic messages 18-58
 escape sequences for Terminal Emulator 12-34 to 12-43
 keyboard controller version, displaying 16-8
 keysym file 5-15, 9-40
 keysyms
 file 5-15, 9-40
 foreign language keyboards 17-1
 LEDs, configuring 9-48
 N-101, details 17-13 to 17-20
 N-107, details 17-36 to 17-43
 N-108, details 17-21 to 17-35
 keyboards (continued)
 N-108LK function keys, programming 12-28 to 12-30
 N-123, details 17-44 to 17-53
 N-97, details 17-4 to 17-12
 type, setting
 in Boot Monitor Setup 11-13
 xserver-keyboard-type parameter 17-2
 VT220-compatible, details 17-21 to 17-35
 Windows 95-compatible 17-13
 Keyclick Volume (Change User Preferences) 9-48
 Keymap Editor
 messages 18-67
 KEYMAPPER messages 18-67
 keymapper, Boot Monitor 11-18
 Keysym File (Change Setup Parameters) 9-40
 keysyms
 file 2-5, 5-15
 foreign-language keyboards 17-1
 keysyms file 9-40
km command (Boot Monitor) 11-8, 11-18
ks command (Boot Monitor) 11-8

L

LAT
 configuration parameters for 9-27
 passwords 9-12
 services in Terminal Host Chooser 12-3
lat-circuit-flush-timeout 9-27
lat-connect-timeout 9-27
lat-keepalive-timeout 9-27
lat-retransmission-limit 9-28
lat-retransmission-timeout 9-28
lat-service-directory-max-size 9-27
lat-service-groups 9-27
 launcher, diagnostic messages 18-133

- Led 1, Led 2, Led 3, Led 4 (Change User Preferences) 9-48
- License Agent Port Number (Change Setup Parameters) 9-28
- License Agents (Change Setup Parameters) 9-28
- License Key (Change Quick Setup) 9-5
- License Key (Change Setup Parameters) 9-28
- LICENSE messages 18-67
- Licensed Features (Change Quick Setup) 9-5
- Licensed Features (Change Setup Parameters) 9-28
- licenses
 - configuration parameters for 9-5, 9-28
 - diagnostic messages 18-67
 - error log file 18-67
 - license server, supplemental documentation for 1-4
- light pen
 - configuration parameters for 9-25
 - diagnostic messages 18-15
- Light Pen Blue Flood (Change Setup Parameters) 9-25
- Load Initial File (Change Setup Parameters) 9-18
- Load Policy (Change Setup Parameters) 9-29
- Loadable Modules Directory (Change Quick Setup) 9-4
- Loadable Modules Directory (Change Setup Parameters) 9-29
- LOADB messages 18-74
- loader, diagnostic messages 18-103
- local clients
 - configuration parameters for 9-18
 - diagnostic messages 18-40
 - environment variables, setting 9-47
- Local Dead Key Support (Change Setup Parameters) 9-25
- Local File Manager
 - configuration parameters for 9-21
 - diagnostic messages 18-44
 - starting from Terminal Emulator 12-2
 - see also* local file system
- local file system
 - booting from 11-7
 - configuration parameters for 9-22
 - diagnostic messages 18-77
 - messages 18-44
 - see also* Local File Manager
- Local Name Cache (Change Setup Parameters) 9-32, 9-37
- LOCALDEV messages 18-77
- Lock Screen Default Password (Change User Preferences) 9-46
- lock screen, configuration parameters for 9-46
- Log File (Change Setup Parameters) 9-20
- Login (Console)
 - diagnostic messages 18-78
- LOGIN messages 18-78
- Login Name (Change Setup Parameters) 9-30
- Login Password (Change Setup Parameters) 9-30
- login, *see* XDM
- login-default-hosts** 9-29
- login-disabled-networks** 9-29
- login-dwlogin-name** 9-30
- login-dwlogin-password** 9-30
- login-ncddm-enabled** 9-30
- login-ncddm-tcp-port** 9-30
- login-restrict-host-choices** 9-29
- login-window-delay-time** 8-17, 9-29
- login-xdm-action-on-disconnect** 8-17, 9-30
- login-xdm-authentication-key** 9-9
- login-xdm-broadcasts** 9-30
- login-xdm-broadcast-wait-time** 9-30
- login-xdm-display-class** 9-29
- login-xdm-indirects** 9-30
- login-xdm-keepalives-begin-time** 8-18, 9-30



login-xdm-keepalives-wait-time 8-19, 9-30
 logout, configuration parameters for 9-46

M

makepsres(1) 13-5

Maximum Gain (Change User
 Preferences) 9-44

Maximum Keepalive Idle Time (Change
 Setup Parameters) 9-36

Maximum Model Clip Planes (Change
 Setup Parameters) 9-33

Maximum Nameset Names (Change Setup
 Parameters) 9-33

Maximum Non-Ambient Lights (Change
 Setup Parameters) 9-33

Maximum Retransmissions (Change Setup
 Parameters) 9-36

Maximum Retries (Change Setup
 Parameters) 9-28

Maximum TCP/IP connections (Change
 Setup Parameters) 9-16

memory

displaying 11-8, 11-9

information, displaying 16-8

statistics 10-27

messages

buffer, size of 18-6

common to all modules 18-7 to 18-14
 configuration parameters for 9-20,
 9-46

configuring 18-5 to 18-6

displaying

Console Messages area 18-4

TELNET connection 18-4

explanations of

CALIBLIGHTPEN 18-15

CALIBTOUCH 18-16

CONFIGD 18-17

CONFUI 18-30

CONSOLE 18-33

DESKTOP 18-36

DHCP 18-37

messages (continued)

explanations of (continued)

DIAGD 18-38

DOS 18-38

downloadable keyboard
 description files 18-58

DTR 18-40

EXECD 18-40

file service 18-87

FILED 18-44

floppy disk drive 18-38

FONT 18-48

font server 18-48

IPROUTE 18-55

JAVA 18-57

KBM 18-58

Keymap Editor 18-67

KEYMAPPER 18-67

launcher 18-133

LICENSE 18-67

LOADB 18-74

local client execution 18-40

Local File Manager 18-44

local file system 18-44, 18-77

LOCALDEV 18-77

LOGIN 18-78

MIRRORD 18-81

module loader 18-103

Motif Window Manager 18-83

MPEGPLAY 18-82

MWM 18-83

NCD Display Manager 18-86

NCD Mosaic Browser 18-74, 18-84,
 18-99

NCD Window Manager 18-133

NCDDM 18-86

ncdwm 18-133

NETD 18-87

NETFILE 18-87

NETSRV 18-93

OPENGL 18-94


PCMCIA card 18-77

- messages (continued)
 - explanations of (continued)
 - PPP 18-96
 - PRINTAPIS 18-99
 - routing 18-55
 - RTLD 18-103
 - SERIALD 18-106
 - SIE 18-108
 - SLIP 18-96
 - SNMPD 18-108
 - TERM 18-109
 - Terminal Emulator 18-109
 - TOKENRING 18-122
 - touch screen 18-16
 - UI 18-125
 - VIDEO 18-82
 - VIDEODECODER 18-82
 - VIDEOPLAYER 18-82
 - WINCEN 18-127
 - WIRELESS 18-128
 - WM 18-133
 - XPRINTD 18-138
 - XREMOTE 18-136
 - XSERVER 18-139
 - XT 18-141
 - extended 18-6
 - format 18-2 to 18-3
 - logging 18-5
 - overview 18-1 to 18-2
 - time stamps 18-5
- MIRRORD messages 18-81
- modules, X server, *see* X server
- modules-directory** 9-4, 9-29
- modules-loaded** 10-8
- modules-load-policy** 9-29
- monitor
 - dots-per-inch, setting 11-13
 - power management, configuration
 - parameters for 9-52
 - resolution, setting 11-13

- MOP (Maintenance Operations Protocol)
 - boot requests, disabling 4-5
 - order of use in booting 4-8
 - server download sequence 4-1, 4-3
- MOP Identify Timeout (Change Setup Parameters) 9-31
- MOP Reset Password (Change Setup Parameters) 9-11
- Motif Window Manager, diagnostic messages 18-83
- Mouse Buttons (Change Setup Parameters) 9-25
- mouse, configuration parameters for 9-25, 9-51
- MPEGPLAY messages 18-82
- multi-homed hosts 3-15
- MWM messages 18-83


N

- N-101 keyboards
 - Boot Monitor, accessing from 17-13
 - escape sequences (in Terminal Emulator) 12-35 to 12-37
 - keycodes 17-14
 - keymap 17-15 to 17-20
 - LEDs 17-13
 - legends 17-14
 - Setup key combination 17-13
 - Windows 95-compatible version 17-13
- N-102 keyboards
 - dead keys (in Terminal Emulator) 12-44
 - escape sequences (in Terminal Emulator) 12-35 to 12-37
- N-107 keyboards
 - Boot Monitor, accessing from 17-36
 - keycodes 17-37
 - keymap 17-38 to 17-43
 - LEDs 17-36
 - legends 17-37
 - Setup key combination 17-36




- N-108 keyboards
 - Boot Monitor, accessing from 17-21
 - keycodes 17-23
 - keymap 17-24 to 17-35
 - LEDs 17-21
 - legends 17-23
 - N-108LK escape sequences (in Terminal Emulator) 12-38 to 12-41
 - N-108LK function keys (in Terminal Emulator) 12-28
 - Setup key combination 17-21
- N-123 keyboards
 - Boot Monitor, accessing from 17-44
 - keycodes 17-45
 - keymap (with OpenWindows) 17-46 to 17-53
 - LEDs 17-44
 - legends 17-45
- N-97 keyboards
 - Boot Monitor, accessing from 17-4
 - escape sequences (in Terminal Emulator) 12-42 to 12-43
 - keycodes 17-5
 - keymap 17-6 to 17-12
 - LEDs 17-4
 - legends 17-5
- name cache 5-10 to 5-11
- Name Cache Max Lifetime (Change Setup Parameters) 9-32, 9-37
- Name Cache Max Size (Change Setup Parameters) 9-32, 9-37
- Name Server Protocol (Change Setup Parameters) 9-37
- Name Server Retransmission Timeout (Change Setup Parameters) 9-37
- Name Server Transaction Timeout (Change Setup Parameters)
 - for DECnet name service 9-32
 - for TCP/IP name service 9-37
- Name Servers (Change Setup Parameters)
 - for DECnet name service 9-32
 - for TCP/IP name service 9-37
- name service
 - configuration parameters for 9-37
 - enabling 5-7
 - name cache, local 5-10 to 5-12
 - name server hosts, specifying 5-8
 - protocol, selecting 5-8
 - remote configuration file entries for 5-7
 - reverse name request 5-12
 - statistics 10-24 to 10-25
- Name Type for Initial TFTP servers (Change Quick Setup) 9-4
- Name Type for Initial TFTP Servers (Change Setup Parameters) 9-22
- Narrow Keysym Tables (Change Setup Parameters) 9-24
- NCD Display Manager
 - configuration parameters for 9-30
 - defined 8-5
 - diagnostic messages 18-86
- NCD Display Manager Enabled (Change Setup Parameters) 9-30
- NCD Display Manager TCP Port Number 9-30
- NCD Mosaic Browser
 - configuration parameters for 9-16 to 9-17
 - diagnostic messages 18-74, 18-84, 18-99
- NCD Terminal Emulator, *see* Terminal Emulator
- NCD Window Manager, diagnostic messages 18-133
- ncd_std** remote configuration file 6-24
- NCD3270 Default Model (Change Setup Parameters) 9-42
- NCD3270 Default Protocol (Change Setup Parameters) 9-42
- NCDDM messages 18-86

- ncddm*(1)**
 - configuration parameters for 9-30
 - defined 8-5
 - diagnostic messages 18-86
- ncdloadprefs*(1)** 6-21
- ncdmkfd*(1)** 13-11
- NCDnet Address (Change Quick Setup) 9-5
- NCDnet Address (Change Setup Parameters) 9-31
- NCDnet Address at Next Boot (Change Quick Setup) 9-5
- NCDnet Address At Next Boot (Change Setup Parameters) 9-31
- NCDnet Name Servers (Change Quick Setup) 9-6
- NCDnet Object Name (Change Setup Parameters)
 - for Configuration daemon 9-19
 - for Diagnostic daemon 9-21
 - for Local File Manager 9-21
 - for Preferences daemon 9-20
- NCDnet Router Address (Change Quick Setup) 9-6
- NCDnet, *see* DECnet
- ncdnet-address*** 9-5, 9-31
- ncdnet-address-at-next-boot*** 9-5, 9-31
- ncdnet-bytes-received*** 10-9
- ncdnet-bytes-sent*** 10-9
- ncdnet-connect-timeout*** 9-31
- ncdnet-count-circuit-down*** 10-9
- ncdnet-data-blocks-received*** 10-9
- ncdnet-data-blocks-sent*** 10-9
- ncdnet-default-router*** 9-6, 9-31
- ncdnet-hello-packets-received*** 10-9
- ncdnet-hello-packets-sent*** 10-9
- ncdnet-hello-timeout*** 9-31
- ncdnet-inbound-errors*** 10-9
- ncdnet-keepalive-timeout*** 9-31
- ncdnet-mop-allow-reset*** 9-31
- ncdnet-mop-identify-timeout*** 9-31
- ncdnet-mop-reset-password*** 9-11
- ncdnet-name-bad-name-errors*** 10-10
- ncdnet-name-cache-hits*** 10-10
- ncdnet-name-cache-max-lifetime*** 9-32
- ncdnet-name-cache-max-size*** 9-32
- ncdnet-name-cache-overflows*** 10-10
- ncdnet-name-local-cache*** 9-32
- ncdnet-name-memory-allocation-failures*** 10-11
- ncdnet-name-no-server-responses*** 10-10
- ncdnet-name-no-such-name-errors*** 10-10
- ncdnet-name-numerical-addresses*** 10-10
- ncdnet-name-requests*** 10-10
- ncdnet-name-server-hits*** 10-10
- ncdnet-name-server-response-errors*** 10-10
- ncdnet-name-servers*** 9-6, 9-32
- ncdnet-name-server-transaction-timeout*** 9-32
- ncdnet-name-system-errors*** 10-10
- ncdnet-node-address*** 10-9
- ncdnet-outbound-errors*** 10-9
- ncdnet-retransmission-limit*** 9-31
- ncdnet-router-timeout*** 9-31
- ncdnet-seconds-since-zeroed*** 10-9
- ncdnet-user-account-name*** 9-31
- ncdquery*(1)** 16-7
- ncdreset*(1)** 16-10 to 16-12
- ncdterm***, *see* Terminal Emulator
- ncdrunterm***, *see* Terminal Emulator
- ncdwm*(1)**
 - diagnostic messages 18-133
 - in XDM session management files 8-9
- net-arp-table-entry-buffers*** 10-12
- net-available-buffers*** 10-11
- net-available-cluster-buffers*** 10-11
- net-buffer-not-available-errors*** 10-11
- net-buffer-waits*** 10-11
- net-connection-control-structure-buffers*** 10-12
- net-connection-name-buffers*** 10-12
- net-connection-option-buffers*** 10-12
- NETD messages 18-87
- net-domain-channel*** 9-33



- net-ethernet-snap-encapsulation** 9-32
- NETFILE** messages 18-87
- net-interface-address-buffers** 10-12
- net-interfaces-table** 10-13
- net-number-of-interfaces** 10-13
- net-packet-data-buffers** 10-12
- net-packet-fragment-reassembly-buffers** 10-12
- net-packet-header-buffers** 10-12
- net-protocol-control-structure-buffers** 10-12
- net-reserved-data-buffers** 10-11
- net-roaming-condition** 9-32
- NETSRV** messages 18-93
- net-token-ring-speed** 9-32
- net-total-buffers** 10-11
- net-total-cluster-buffers** 10-11
- network**
 - buffers, statistics 10-11
 - connection requests, diagnostic daemons 18-87
 - interfaces, statistics 10-13
 - TCP performance tuning 5-31 to 5-34
- network services**
 - address discovery 3-1 to 3-16
 - address resolution 5-5 to 5-6
 - booting 4-1 to 4-19
 - defaults 5-3 to 5-4
 - file access 5-13 to 5-24
 - name service 5-7 to 5-12
 - overview 5-1 to 5-2
 - routing 5-25 to 5-31
 - time service 9-38
 - X server loading 4-1 to 4-19
- nf** command (Boot Monitor) 11-8
- NFS (Network File System)**
 - auto-save of configuration data 6-35
 - booting 4-3, 4-5, 4-8, 4-13
 - file service 5-22 to 5-23
 - font service 7-6
 - message logging 18-5
 - statistics 10-13 to 10-16
 - unmount timer 5-23
- NFS Directory (Change Setup Parameters)** 9-15
- NFS Server Access Control Default (Change Setup Parameters)** 9-12
- NFS Server Access Control List (Change Setup Parameters)** 9-12
- NFS Unmount Timeout (Change Setup Parameters)** 9-22
- nfs-directory-contents-requests** 10-14
- nfs-directory-create-requests** 10-14
- nfs-directory-remove-requests** 10-14
- nfs-file-create-requests** 10-14
- nfs-file-remove-requests** 10-14
- nfs-file-rename-requests** 10-14
- nfs-get-attributes-requests** 10-13
- nfs-get-file-system-stats-requests** 10-15
- nfs-get-root-requests** 10-13
- nfs-link-create-requests** 10-14
- nfs-null-requests** 10-13
- nfs-path-lookup-requests** 10-13
- nfs-read-data-requests** 10-14
- nfs-read-symlink-requests** 10-13
- nfs-received-directory-contents-requests** 10-16
- nfs-received-directory-create-requests** 10-16
- nfs-received-directory-remove-requests** 10-16
- nfs-received-file-create-requests** 10-15
- nfs-received-file-remove-requests** 10-15
- nfs-received-file-rename-requests** 10-15
- nfs-received-get-attributes-requests** 10-15
- nfs-received-get-file-system-stats-requests** 10-16
- nfs-received-get-root-requests** 10-15
- nfs-received-link-create-requests** 10-16
- nfs-received-null-requests** 10-15
- nfs-received-path-lookup-requests** 10-15
- nfs-received-read-data-requests** 10-15
- nfs-received-read-symlink-requests** 10-15
- nfs-received-set-attributes-requests** 10-15
- nfs-received-symlink-create-requests** 10-16
- nfs-received-write-data-cache-requests** 10-15



nfs-received-write-data-requests 10-15
nfs-set-attributes-requests 10-13
nfs-symlink-create-requests 10-14
nfs-write-data-cache-requests 10-14
nfs-write-data-requests 10-14
Nominal Edge Width (Change User Preferences) 9-50
Nominal Line Width (Change User Preferences) 9-50
Nominal Marker Size (Change User Preferences) 9-50
Number of colors (Change Setup Parameters) 9-40
nv command (Boot Monitor) 11-8, 11-20
NVRAM
 addresses, storing in 3-11, 11-14
 configuration parameters saved in 11-38
 contents of 11-24 to 11-39
 optional string space 11-37
 reading values from 9-7
 saving data to 6-35, 11-12
NVRAM utility
 commands 11-20 to 11-21
 sample sessions 11-21
 starting 11-20


O

Offset from Greenwich Mean Time (Change Setup Parameters) 9-38
Open Timeout (Change Setup Parameters) 9-24
OpenGL
 configuration parameters for 9-48
 diagnostic messages 18-94
Optional Features (Change Setup Parameters) 9-28
outline fonts, *see* font server

P

Parallel Daemon LAT Service Passwords (Change Setup Parameters) 9-12

Parallel Daemons Table (Change Setup Parameters) 9-33
parallel port
 access control 15-10
 configuration parameters for 9-33
 configuring 15-8
 statistics 10-16
 uses for 15-2
parallel-daemons-lat-service-passwords 9-12
parallel-daemons-table 9-33
Password (Change Setup Parameters, File Manager Section) 9-12
passwords
 displaying 6-5
 LAT 9-12
 lock screen 9-46
 saved in NVRAM optional string space 11-37
 SNMP community names 16-5, 16-6
PCMCIA cards
 messages 18-77
 see also local file system; Local File Manager
Permit Old X Bugs (Change User Preferences) 9-45
Persist in Loading (Change Setup Parameters) 9-14
Persistent Loading (Change Setup Parameters) 9-18
PEX
 3D mouse 14-13
 configuration parameters for 9-33 to 9-35, 9-50, 14-3 to 14-13
 digitizing tablet 14-13
 fonts 14-2
 input devices 14-13
 licensing 14-3
 requirements 14-3
 terminals supported on 14-1
 troubleshooting 14-14
pex-max-model-clip-planes 9-33, 14-4
pex-max-nameset-names 9-33, 14-4



- pex-max-non-ambient-lights** 9-33, 14-4
- pex-monitor-reference-blue-u** 9-34, 14-6
- pex-monitor-reference-blue-v** 9-34, 14-6
- pex-monitor-reference-blue-y** 9-34, 14-6
- pex-monitor-reference-green-u** 9-34, 14-6
- pex-monitor-reference-green-v** 9-34, 14-7
- pex-monitor-reference-green-y** 9-34, 14-7
- pex-monitor-reference-red-u** 9-34, 14-7
- pex-monitor-reference-red-v** 9-34, 14-7
- pex-monitor-reference-red-y** 9-34, 14-8
- pex-monitor-reference-white-u** 9-35, 14-8
- pex-monitor-reference-white-v** 9-35, 14-8
- pex-monitor-reference-white-y** 9-35, 14-8
- Physical Location (Change Setup Parameters) 9-38
- pi** command (Boot Monitor) 11-9
- pointing devices, configuration parameters for 9-51
- ports
 - 3270 terminal emulator 9-42
 - Configuration daemon 6-28
 - NCD Display Manager 9-30
 - Preferences daemon 6-29
 - XRemote 9-41
 - see also* serial port; parallel port
- power management (monitor), configuration parameters for 9-52
- Powerdown After (Change User Preferences) 9-52
- PPP
 - configuration parameters for 9-35
 - diagnostic messages 18-96
- PPP and SLIP Interfaces Table (Change Setup Parameters) 9-35
- PPP Interfaces Table (Change Setup Parameters) 9-35
- PPPD messages 18-96
- ppp-interfaces-table** 9-35
- ppp-slip-interfaces-table** 9-35
- pref-audio-maximum-gain** 9-44
- pref-bell-duration** 9-45
- pref-bell-enable** 9-45
- pref-bell-pitch** 9-45
- pref-bell-volume** 9-45
- pref-compatibility-decwindows-images** 9-45
- pref-compatibility-decwindows-keyboard** 17-12, 17-20, 17-29, 17-35
- pref-compatibility-decwindows-keyboards** 9-45
- pref-compatibility-decwindows-vendor-string** 9-45
- pref-compatibility-permit-old-x-bugs** 9-45
- pref-console-auto-lock-idle-time** 9-46
- pref-console-auto-logout-cancel-delay** 9-46
- pref-console-auto-logout-idle-time** 9-46
- pref-console-blank-screen-delay** 9-46
- pref-console-key-sequence** 9-46
- pref-console-lock-screen-default-password** 9-46
- pref-console-show-timestamps** 9-46
- pref-environment** 9-47
- Preferences daemon
 - configuration parameters for 9-20
 - defined 6-2
 - ports for accessing 6-29
 - starting from Terminal Emulator 12-2
- pref-font-extended-diagnostics** 7-17, 9-47
- pref-font-path** 7-12, 9-47
- pref-keyboard-auto-repeat** 9-47
- pref-keyboard-auto-repeat-rate** 9-48
- pref-keyboard-auto-repeat-start** 9-47
- pref-keyboard-function-key-style** 9-47
- pref-keyboard-keyclick-volume** 9-48
- pref-keyboard-leds** 9-48
- pref-mouse-acceleration** 9-51
- pref-mouse-arrangement** 9-51
- pref-mouse-threshold** 9-51
- pref-pex-color-clipping-method** 9-50, 14-12
- pref-pex-dither-flat-shaded-surface** 9-50, 14-10
- pref-pex-dither-interpolated-surface** 9-50, 14-10
- pref-pex-nominal-edge-width** 9-50, 14-9

pref-pex-nominal-line-width 9-50, 14-9, 14-10
pref-pex-nominal-marker-size 9-50
pref-pex-surface-interior-style 9-50, 14-11
pref-pex-surface-interp-method 9-50, 14-11
pref-pex-surface-reflect-model 9-50, 14-12
pref-power-manage-enable 9-52
pref-power-manage-powerdown-time 9-52
pref-power-manage-standby-time 9-52
pref-power-manage-suspend-time 9-52
pref-screen-background-bitmap-background 9-53
pref-screen-background-bitmap-file 9-52
pref-screen-background-bitmap-foreground 9-53
pref-screen-background-color 9-52
pref-screen-background-type 9-52
pref-screensaver-bitmap-file 9-53
pref-screensaver-enable 9-53
pref-screensaver-exposures 9-53
pref-screensaver-interval 9-53
pref-screensaver-style 9-53
pref-screensaver-time 9-53
pref-sie-contrast-threshold 9-54
pref-sie-sampling-method 9-54
pref-xserver-backing-store 9-54
pref-xserver-benchmark-optimizations 9-54
pref-xserver-current-pointing-device 9-51
pref-xserver-graphics-optimizations 9-54
pref-xserver-screen-resolution 9-54
pref-xserver-touchscreen-button-press-threshold 9-51
pref-xserver-touchscreen-button-release-threshold 9-51
Previous Server (Change Setup Parameters) 9-14
Previous Source (Change Setup Parameters) 9-14
Primary Boot Source (Change Setup Parameters) 9-14
PRINTAPIS messages 18-99


protect command (Configuration language) 6-32
PU2.1 Default Host (Change Setup Parameters) 9-42
PU2.1 Default tcp Port (Change Setup Parameters) 9-42
pwireless-interface-table 10-28
pwireless-statistics-table 10-28

Q

Query for Unit Name at Boot (Change Setup Parameters) 9-38

R

RARP (Address Resolution Protocol) 3-10
rarpd(8) 3-10
read command (Configuration language) 6-19 to 6-20
Read Timeout (Change Setup Parameters) 9-24
Receive Buffer Size (Change Setup Parameters) 9-36
Reconnect attempts before failure (Change Setup Parameters) 9-24
Reference Blue Chromaticity (Change Setup Parameters) 9-34
Reference Blue Luminance (Change Setup Parameters) 9-34
Reference Green Chromaticity (Change Setup Parameters) 9-34
Reference Green Luminance (Change Setup Parameters) 9-34
Reference Red Chromaticity (Change Setup Parameters) 9-34
Reference Red Luminance (Change Setup Parameters) 9-34
Reference White Chromaticity (Change Setup Parameters) 9-35
Reference White Luminance (Change Setup Parameters) 9-35
registers, displaying 11-8




- remote configuration
 - apply** command 6-34
 - assignment statements 6-11, 6-14
 - assignments, order of 6-14
 - auto-save 6-34 to 6-37
 - configuration commands 6-8 to 6-10
 - get-protect** command 6-33
 - parameters
 - "<GET-PROTECTED>" value 6-32
 - "default" parameter value 6-12
 - "nil" parameter value 6-5
 - accessing through SNMP 16-10
 - assigning values 6-11 to 6-12
 - default values 6-12
 - filenames as parameter
 - values 6-13
 - groups 6-6
 - multiple assignments of same
 - parameter 6-14
 - protecting 6-32 to 6-33
 - saved in NVRAM 11-38
 - saved in optional string area 11-37
 - tables, assigning values 6-11 to 6-12
 - write-only 6-5
 - protect** command 6-32
 - read** command 6-19 to 6-20
 - remote terminal, accessing 9-8
 - set-protect** command 6-33
 - syntax rules 6-13 to 6-15
 - see also* remote configuration files
- remote configuration files
 - auto-save file 6-36
 - comments in 6-14
 - configuration parameters for 9-18
 - creating 6-16 to 6-21
 - by **ncdinstall** 6-17
 - from sample file 6-17
 - from Setup menus 6-18
 - directory for 6-26
- remote configuration files (continued)
 - downloading
 - disabling 6-25, 6-27
 - hosts for 6-21
 - initial file servers 5-13, 6-21
 - persistent 6-22
 - sequence of filenames 6-23
 - file permissions 6-18
 - file size not restricted 6-18
 - filenames
 - custom 6-23
 - hexadecimal, converting to 6-17
 - optional 6-23
 - standard 6-16, 6-23 to 6-25
 - hexadecimal, converting IP address
 - to 6-17
 - ncd_std** generic file 6-24
 - nesting files 6-19
 - NVRAM, saving data to 6-15
 - Restore Defaults, file for 6-27
 - sample file 6-17
 - .stp** file 6-36
 - user's file, including 6-20
 - see also* remote configuration; Setup menus (Console)
- remote reset (using SNMP) 16-10 to 16-12
- Reopen Timeout (Change Setup Parameters) 9-24
- Rescan Messages command (Console) 18-4
- reset, remote 16-10 to 16-12
- Respond to Broadcast ICMP (Change Setup Parameters) 9-26
- Restore Defaults (Setup menus) 6-27
- Restrict Host Choices (Change Setup Parameters)
 - for login through the Terminal Emulator 9-39
 - for login through XDM 9-29
- Retain X Settings Across Sessions (Change Setup Parameters) 9-40

Retransmission Limit (Change Setup Parameters) 9-28, 9-31
Retransmission Timeout (Change Setup Parameters) 9-28
reverse name request 3-15
RGB File (Change Setup Parameters) 9-40
rgb.txt file
 default location 5-15
 initial file server hosts 5-13
 renaming 9-40
Ring Bell (Change User Preferences) 9-45
Roaming Condition (Change Setup Parameters) 9-32
Router Timeout (Change Setup Parameters) 9-31
routing
 configuration parameters for 9-25
 gateways
 default 5-25
 boot host, used as gateway 5-25
 messages 18-55
 proxy ARP 5-29
 router discovery 5-30
 routing table 5-26 to 5-29
Routing Table (Change Setup Parameters) 9-26
rs command (Boot Monitor) 11-9
RTLD messages 18-103

S

Save Screen After (Change User Preferences) 9-53
Screen Background Type (Change User Preferences) 9-52
screen background, configuration parameters for 9-52
screen resolution
 displaying 9-54
 setting 11-13
Screen Resolution (Change User Preferences) 9-54

Screen Saver Bitmap File (Change User Preferences) 9-53
Screen Saver Style (Change User Preferences) 9-53
screen saver, configuration parameters for 9-53
se command (Boot Monitor) 11-9, 11-12
Secondary Boot Source (Change Setup Parameters) 9-14
Secondary TCP/IP Server (Change Setup Parameters) 9-14
security, *see* assess control; passwords
Send Broadcast ICMP for Subnet Mask (Change Setup Parameters) 9-15
Send Buffer Size (Change Setup Parameters) 9-36
Serial and Parallel Access Control List (Change Setup Parameters) 9-13
Serial Daemon LAT Service Passwords (Change Setup Parameters) 9-12
Serial Daemons Table (Change Setup Parameters) 9-35
Serial Interfaces Table (Change Setup Parameters) 9-35
serial port
 access control 15-10
 configuration parameters for 9-35
 configuring
 serial-daemons-table 15-6 to 15-8
 serial-interfaces-table 15-2 to 15-6
 diagnostic messages 18-106
 numbering (1 through 3) 15-2
 serial sessions, automatic display in Terminal Host Chooser 12-3
 serial terminal emulation, configuring 12-3
 statistics 10-17 to 10-18
 system console, configuring terminal as 15-9
 uses for 15-1
serial-access-control-enabled 9-13, 15-10
serial-access-control-list 9-13



- SERIALD messages 18-106
- serial-daemons-lat-service-passwords** 9-12
- serial-daemons-table** 9-35
- serial-interfaces-table** 9-35, 12-4, 15-2, 15-10
- Service Directory Max Size (Change Setup Parameters) 9-27
- Service Groups (Change Setup Parameters) 9-27
- set-protect** command (Configuration language) 6-32, 6-33
- Setup (Boot Monitor)
 - keymapper for 11-18
 - navigating in 11-13
 - setting parameters 11-13 to 11-17
 - starting 11-12
- Setup menus (Console)
 - auto-save 6-34 to 6-37
 - Change Quick Setup
 - commands and buttons 9-1 to 9-2
 - fields, corresponding parameters 9-3 to 9-6
 - fields, described 9-3 to 9-6
 - remote terminal, configuring 9-2
 - Change Setup Parameters
 - commands and buttons 9-7 to 9-8
 - fields, corresponding parameters 9-8 to 9-42
 - fields, described 9-8 to 9-42
 - remote terminal, configuring 9-8
 - Change User Preferences
 - commands and buttons 9-43 to 9-44
 - fields, corresponding parameters 9-44 to 9-54
 - fields, described 9-44 to 9-54
 - remote terminal, configuring 9-43
 - connecting to remote terminal through 9-2
 - disabling 6-34
 - Restore Defaults 6-27
 - see also* terminal configuration; remote configuration
- Show Console Message Timestamps (Change User Preferences) 9-46
- Show Extended Font Diagnostics (Change User Preferences) 9-47
- Show Low Memory Warning Box at (Change Setup Parameters) 9-39
- Show Statistics (Console)
 - commands and buttons 10-1 to 10-2
 - fields, corresponding parameters 10-2 to 10-31
 - fields, descriptions 10-2 to 10-31
 - remote terminal, connecting to 10-1
 - starting 10-1
- Show Tool Bar (Change Setup Parameters) 9-16
- SIE
 - configuration parameters for 9-54
 - diagnostic messages 18-108
- SIE Contrast Threshold (Change User Preferences) 9-54
- SIE Sampling Method (Change User Preferences) 9-54
- SLIP
 - configuration parameters for 9-35
 - diagnostic messages 18-96
- sm** command (Boot Monitor) 11-9
- SMTP Email Server (Change Setup Parameters) 9-17
- SNMP Read-Only Community (Change Setup Parameters) 9-10
- SNMP (Simple Network Management Protocol)
 - access control 16-3 to 16-7
 - community names 16-3 to 16-7
 - components 16-1
 - connecting to a terminal 16-10
 - diagnostic messages 18-108
 - host requirements 16-1, 16-3
 - manager hosts 16-4

SNMP (Simple Network Management Protocol) (continued)

MIB files

default locations 16-2

defined 16-2

mib.my file 16-2**mib.txt** file 16-2**MIBFILE** environment

variable 16-3

monitor hosts 16-5 to 16-6

ncdquery 16-7 to 16-9**ncdreset** 16-10, 16-11

object names and paths for

configuration parameters 16-2

overview 16-1 to 16-3

rebooting 16-10

remote reset/reboot 16-10 to 16-12

statistics 10-18 to 10-21

trap events 16-6

variables

reading 16-7

writing 16-9

X session, restarting 16-10

SNMP Read-Only Access Control List

(Change Setup Parameters) 9-11

SNMP Read-Only Alternative Community

(Change Setup Parameters) 9-10

SNMP Read-Write Access Control List

(Change Setup Parameters) 9-11

SNMP Read-Write Alternative Community

(Change Setup Parameters) 9-11

SNMP Read-Write Community (Change


Setup Parameters) 9-11

SNMP Trap Monitors (Change Setup

Parameters) 9-11

snmp-allow-reset 9-11, 16-11, 16-12**snmp-bad-variable-name-error-responses-**
received 10-19**snmp-bad-variable-name-error-responses-**
transmitted 10-20**snmp-bad-variable-values-error-responses-**
received 10-19**snmp-bad-variable-values-error-responses-**
transmitted 10-20

SNMPD messages 18-108


snmp-general-error-responses-
received 10-19**snmp-general-error-responses-**
transmitted 10-20**snmp-get-next-requests-received** 10-20**snmp-get-next-requests-transmitted** 10-20**snmp-get-requests-received** 10-19**snmp-get-requests-transmitted** 10-20**snmp-get-responses-received** 10-20**snmp-get-responses-transmitted** 10-20**snmp-packets-received** 10-18**snmp-packets-received-with-asn1-**
errors 10-19**snmp-packets-received-with-bad-**
community-names 10-18**snmp-packets-received-with-bad-**
community-uses 10-18**snmp-packets-received-with-bad-variable-**
types 10-19**snmp-packets-received-with-bad-**
versions 10-18**snmp-packets-transmitted** 10-18**snmp-read-only-access-control-**
enabled 9-11, 16-5**snmp-read-only-access-control-list** 9-11, 16-5**snmp-read-only-community** 9-10**snmp-read-only-community-alt** 9-10**snmp-read-only-variable-error-responses-**
received 10-19**snmp-read-only-variable-error-responses-**
transmitted 10-20**snmp-read-write-access-control-**
enabled 9-11, 16-4, 16-11**snmp-read-write-access-control-list** 16-4,
16-11**snmp-read-write-community** 9-11, 16-11**snmp-read-write-community-alt** 9-11**snmp-set-requests-received** 10-20**snmp-set-requests-transmitted** 10-20

- snmp-too-big-error-responses-received** 10-19
- snmp-too-big-error-responses-transmitted** 10-20
- snmp-trap-monitors** 9-11
- snmp-traps-received** 10-20
- snmp-traps-transmitted** 10-21
- snmp-variable-gets-completed** 10-19
- snmp-variable-sets-completed** 10-19
- SOCKS Host (Change Setup Parameters)** 9-17
- SOCKS Port (Change Setup Parameters)** 9-17
- Solid Color (Change User Preferences)** 9-52
- Standby After (Change User Preferences)** 9-52
- Startup Commands (Change Setup Parameters)** 9-18
- Starworks volume file (Change Setup Parameters)** 9-39
- statistics**
 - DECnet 10-9 to 10-11
 - displaying 10-1
 - Ethernet 10-2
 - font usage 10-3
 - ICMP 10-3 to 10-5
 - IP 10-6, 10-8
 - memory 10-27
 - name service 10-24 to 10-25
 - network buffers 10-11
 - network interfaces 10-13
 - NFS 10-13
 - parallel port 10-16
 - serial port 10-17 to 10-18
 - SNMP 10-18, 10-21
 - TCP 10-21 to 10-23
 - TFTP 10-25
 - UDP 10-26
 - wireless 10-28 to 10-29
 - X server modules 10-8
 - XRemote 10-30 to 10-31
- subnet mask**
 - setting 3-13 to 3-15
 - storing in NVRAM 3-11
- Subnet Mask (Change Quick Setup)** 9-5
- Subnet Mask (Change Setup Parameters)** 9-25
- Sun Type 4-compatible keyboard** 17-36
- Sun Type 5-compatible keyboard** 17-44
- Surface Interior Style (Change User Preferences)** 9-50
- Surface Interpolation Method (Change User Preferences)** 9-50
- Surface Reflection Model (Change User Preferences)** 9-50
- Suspend After (Change User Preferences)** 9-52
- system console, configuring terminal as** 15-9

T


- TCP**
 - configuration parameters for 9-36
 - default linger time, configuring 5-33
 - maximum retransmissions, configuring 5-33
 - performance tuning 5-31 to 5-34
 - ports
 - 3270 terminal emulator 9-42
 - Configuration daemon 9-19
 - Diagnostic daemon 9-20
 - for configuring terminals 6-28 to 6-29
 - Local File Manager 9-21
 - NCD Display Manager 9-30
 - User Preferences daemon 9-20
 - XRemote 9-41
 - segment sizes larger than the default 5-33
 - send and receive buffers 5-31
 - statistics 10-21 to 10-23
 - timeout, configuring 5-32

- TCP Port Number (Change Setup Parameters)
 - for Configuration daemon 9-19
 - for Diagnostics daemon 9-20
 - for Local File Manager 9-21
 - for User Preferences daemon 9-20
 - for XRemote 9-41
- TCP/IP Name Servers (Change Quick Setup) 9-5
- TCP/IP Name Service Protocol (Change Quick Setup) 9-5
- TCP/IP Broadcast Boot Request (Change Setup Parameters) 9-15
- TCP/IP Desired Server (Change Setup Parameters) 9-14
- tcp-ack-only-packets-transmitted** 10-23
- tcp-ack-packets-received** 10-23
- tcp-active-connect-attempts** 10-21
- tcp-connections-reset** 10-22
- tcp-connections-timed-out-on-keepalives** 10-22
- tcp-connections-timed-out-on-retransmissions** 10-22
- tcp-connection-table** 10-23
- tcp-connect-timeout** 5-32, 9-36
- tcp-default-linger-time** 5-33, 9-36
- tcp-default-mss-for-non-local** 5-33
- tcp-established-connections** 10-22
- tcp-failed-connect-attempts** 10-22
- tcpip-arp-cache** 5-5, 9-13
- tcpip-arp-complete-entry-timeout** 5-6, 9-13
- tcpip-arp-incomplete-entry-timeout** 5-6, 9-13
- tcpip-dns-default-domain** 5-9, 9-37
- tcpip-dns-domain-search** 9-37
- tcpip-name-bad-name-errors** 10-24
- tcpip-name-cache-hits** 10-24
- tcpip-name-cache-max-lifetime** 5-10, 9-37
- tcpip-name-cache-max-size** 5-11, 9-37
- tcpip-name-cache-overflows** 10-24
- tcpip-name-local-cache** 9-37
- tcpip-name-memory-allocation-failures** 10-25
- tcpip-name-no-server-responses** 10-24
- tcpip-name-numerical-addresses** 10-24
- tcpip-name-requests** 10-24
- tcpip-name-server-hits** 10-24
- tcpip-name-server-protocol** 5-8, 9-5, 9-37
- tcpip-name-server-response-errors** 10-24
- tcpip-name-server-retransmission-timeout** 5-11, 9-37
- tcpip-name-servers** 5-8, 9-5, 9-37
- tcpip-name-server-transaction-timeout** 5-12, 9-37
- tcpip-name-system-errors** 10-24
- tcpip-no-such-name-errors** 10-24
- tcp-keepalive-idle-time** 9-36
- tcp-keepalive-interval** 9-36
- tcp-keepalive-packets-transmitted** 10-23
- tcp-maximum-number-of-connections** 10-21
- tcp-maximum-retransmission-time** 10-21
- tcp-max-keepalive-idle-time** 9-36
- tcp-max-retransmissions** 5-33, 9-36
- tcp-minimum-retransmission-time** 10-21
- tcp-packets-received** 10-22
- tcp-packets-retransmitted** 10-23
- tcp-packets-transmitted** 10-22
- tcp-packets-with-errors-received** 10-23
- tcp-passive-connects-attempts** 10-21
- tcp-receive-buffer-size** 5-31, 9-36
- tcp-reset-packets-transmitted** 10-23
- tcp-retransmission-algorithm-type** 10-21
- tcp-send-buffer-size** 5-32, 9-36
- TELNET
 - for terminal configuration 6-28
 - for viewing messages 18-4
 - ports
 - Configuration daemon 9-19
 - Diagnostic daemon 9-20
 - for configuring terminals 6-28 to 6-29
 - Local File Manager 9-21
 - User Preferences daemon 9-20
 - services in Terminal Host Chooser 12-3




Telnet Port Number (Change Setup Parameters)
 for Configuration daemon 9-19
 for Diagnostic daemon 9-20
 for Local File Manager 9-21
 for User Preferences daemon 9-20
 TERM messages 18-109
term, *see* Terminal Emulator
term-default-connect-timeout 9-39
term-default-hosts 9-39
term-delay-lat-display 9-39
 terminal configuration
 access control 6-30 to 6-34
 Boot Monitor Setup menus 11-12 to 11-19
 default terminal configuration, defined 6-2
 diagnostic messages 18-17
 methods overview 6-2 to 6-5
 NVRAM utility 11-20 to 11-37
 parameters
 groups 6-6 to 6-7
 types 6-5
 Setup menus (Console) 9-1 to 9-54
 using SNMP 16-7
 using TELNET 6-28
 see also remote configuration; remote configuration files; Setup menus (Console); Setup (Boot Monitor); NVRAM Utility
 Terminal Default Connect Timeout (Change Setup Parameters) 9-39
 Terminal Emulator
 answer-back message 12-12
 character coding 12-51 to 12-59
 character sets supported 12-51
 color text, configuring 12-30
 configuration parameters for 9-6, 9-39
 Cursors menu 12-11
 dead-key support 12-44
 diagnostic messages 18-109
 disconnecting, delay 12-12

Terminal Emulator (continued)
 escape sequences 12-13 to 12-33
 File menu, configuring 12-6
 fonts
 choosing 12-5
 Default 12-10
 Fonts menu 12-10
 icon titles, configuring 12-30
 key translations 12-4
 keyboards
 compose sequences 12-44 to 12-50
 downloadable descriptions 17-54
 escape sequences 12-34 to 12-43
 Keys menu 12-11
 N-108LK function keys,
 programming 12-28
 Options menu, configuring 12-8
 resources
 answerbackString 12-12
 appCursorMode 12-9
 appKeypadMode 12-9
 autoLineFeed 12-8
 autoWrap 12-8
 blinkCursor 12-10
 c132 12-9
 clearScreenWithBlanks 12-9
 curses 12-9
 defaultHost 12-7
 disableExits 12-6, 12-7
 disconnectDelay 12-12
 family 12-11
 foundry 12-11
 jumpScroll 12-8
 latin1Font 12-10
 localFlowControl 12-9
 marginBell 12-9
 menuBar 12-6, 12-8
 pointSize 12-11
 printerHost 12-7
 rectangularCutLineTerminator 12-12
 reverseVideo 12-8



- Terminal Emulator (continued)
 - resources (continued)
 - reverseWrap** 12-8
 - saveLines** 12-6
 - scrollbar** 12-6
 - secureKeyboard** 12-10
 - showAvailableLat** 12-3
 - showCTerm** 12-3
 - showDefaultLat** 12-3
 - showLocal** 12-2
 - showSerial** 12-3
 - showTelnet** 12-3
 - statusLine** 12-10
 - stripParity** 12-10
 - subFont** 12-11
 - useCondensedFont** 12-9
 - visualBell** 12-8
 - scroll bars, configuring 12-6
 - selecting text, terminator for 12-12
 - serial connections, configuring 12-3
 - status line, configuring 12-27
- Terminal Host Chooser
 - local service connections 12-2
 - X resources for 12-3
 - window titles, configuring 12-30
- Terminal IP Address At Next Boot (Change Quick Setup) 9-5
- Terminal Session (Change Quick Setup) 9-6
- term-restrict-host-choices** 9-39
- Tertiary Boot Source (Change Setup Parameters) 9-14
- Tertiary TCP/IP Server (Change Setup Parameters) 9-14
- Test RAM at power-up (Change Setup Parameters) 9-13
- TFTP
 - auto-save of configuration data 6-35
 - booting 4-2, 4-5, 4-8, 4-12
 - file service 5-20 to 5-22
 - statistics 10-25
- TFTP Directory (Change Setup Parameters) 9-15
 - tftp-ack-packets-received** 10-25
 - tftp-ack-packets-transmitted** 10-26
 - tftp-bad-access-error-responses-received** 10-25
 - /tftpboot** directory 4-15
 - tftpd(8)** 5-21
 - tftp-data-packets-received** 10-25
 - tftp-data-packets-transmitted** 10-25
 - tftp-disk-full-error-responses-received** 10-25
 - tftp-file-read-requests-transmitted** 10-25
 - tftp-file-write-requests-transmitted** 10-25
 - tftp-no-available-buffer-errors** 10-25
 - tftp-no-file-error-responses-received** 10-25
 - tftp-packets-retransmitted** 10-26
- Threshold Distance (Change User Preferences) 9-51
- Time Server (Change Setup Parameters) 9-38
- Time Server Retries (Change Setup Parameters) 9-38
- Time Server Timeout (Change Setup Parameters) 9-38
- time service, configuration parameters for 9-38
 - time-offset-from-gmt** 9-38
 - time-server** 9-38
 - time-server-retries** 9-38
 - time-server-timeout** 9-38
- Timestamp Frequency (Change Setup Parameters) 9-20
- time-zone** 9-38
- Timezone (Change Setup Parameters) 9-38
- TN3270 Default Host (Change Setup Parameters) 9-42
- TN3270 Default tcp Port (Change Setup Parameters) 9-42



Token-Ring
 configuration parameters for 9-32
 current and built-in addresses 3-7
 diagnostic messages 18-122
 interface speed, setting (HMX
 terminals) 11-9
 TOKENRING messages 18-122
 Token-Ring Speed (Change Setup
 Parameters) 9-32
tokring-interface-table 10-26
tokring-statistics-table 10-26
 touch screen
 configuration parameters for 9-25,
 9-51
 diagnostic messages 18-16
tr command (Boot Monitor) 11-9
 Transaction Timeout (Change Setup
 Parameters) 9-28
 Try All Matches on Open (Change Setup
 Parameters) 9-22
 Try Generic Filename (Change Setup
 Parameters) 9-19
 Try MOP (Change Setup Parameters) 9-15
 Try MOP with File Name (Change Setup
 Parameters) 9-15
 Try TCP/IP Product Name and Memory
 Size File (Change Setup
 Parameters) 9-15
 Try TCP/IP Product Name and Memory
 Size with Path File (Change Setup
 Parameters) 9-15
 Try TCP/IP Product Name File (Change
 Setup Parameters) 9-15
 Try TCP/IP Product Name with Path File
 (Change Setup Parameters) 9-15
 Try TCP/IP Unit Address File (Change
 Setup Parameters) 9-15
 Try TCP/IP Unit Address with Path File
 (Change Setup Parameters) 9-15
 Try Unit Ethernet Address as Filename
 (Change Setup Parameters) 9-19
 Try Unit IP Address as Filename 9-19

Try Unit Name as Filename (Change
 Setup Parameters) 9-19
 Try Unit NCDnet Address as Filename
 (Change Setup Parameters) 9-19

U

ud command (Boot Monitor) 11-9
 UDP, statistics 10-26
udp-listener-table 10-27
udp-packets-received 10-26
udp-packets-received-with-errors 10-26
udp-packets-received-with-unknown-
 port 10-26
udp-packets-transmitted 10-26
 UI messages 18-125
 Unit Global Password (Change Setup
 Parameters) 9-9
 Unit Name (Change Setup
 Parameters) 9-38
unit-administrative-status 9-38, 16-11, 16-12
unit-blocks-of-available-memory 10-28
unit-boot-monitor-version 10-27
unit-code-memory-installed 10-27
unit-contact 9-38
unit-floating-point-exceptions 10-28
unit-global-password 9-9
unit-idle-time 10-27
unit-keyboard-controller-version 10-27
unit-licensed-features 9-5, 9-28
unit-license-key 9-5, 9-28
unit-location 9-38
unit-low-memory-level 9-39
unit-memory-available 10-28
unit-memory-installed 10-27
unit-name 9-38
unit-optional-features 9-28
unit-query-for-name-at-boot 3-15, 5-12, 9-38
unit-snmp-system-object-id 10-27
unit-tcpip-service-level 10-27
unit-terminal-model 10-27
unit-time-since-boot 10-27
unit-version 10-27


- UNIX Config Directory (Change Quick Setup) 9-4
- UNIX Directory (Change Setup Parameters) 9-18
- up** command (Boot Monitor) 11-9, 11-10
- Use Address Discovery (Change Quick Setup) 9-5
- Use Address Discovery (Change Setup Parameters) 9-26
- Use Backing Store (Change User Preferences) 9-54
- Use Decimal IP Address Notation as Filename (Change Setup Parameters) 9-19
- Use Proxy Arp (Change Setup Parameters) 9-26
- Use Router Discovery (Change Setup Parameters) 9-26
- Use Router Solicit (Change Setup Parameters) 9-26
- Use SNAP (802.2 LLC) Encapsulation on Ethernet (Change Setup Parameters) 9-32
- Use WinCenter Colors (Change Setup Parameters) 9-40
- User Account Name (Change Setup Parameters) 9-31
- User Preferences daemon
 - configuration parameters for 9-20
 - defined 6-2
 - ports for accessing 6-29
 - starting from Terminal Emulator 12-2
- User Preferences Read-Only Password (Change Setup Parameters) 9-10
- User Preferences Read-Write Password (Change Setup Parameters) 9-10
- /usr/lib/X11/ncd/configs** directory 6-26
- /usr/lib/X11/ncd/dps** (DPS directory) 13-10
- /usr/lib/X11/ncd/fs** (font server directory) 7-23
- /usr/lib/x11/ncd/snmp/** (SNMP directory) 16-2

V

- video
 - configuration parameters for 9-39
 - diagnostic messages 18-82
- VIDEO messages 18-82
- VIDEODECODER messages 18-82
- VIDEOPLAYER messages 18-82
- visual, default 9-41
- VMS Config Directory (Change Quick Setup) 9-4
- VMS Directory (Change Setup Parameters) 9-18
- VT220-compatible keyboards
 - Boot Monitor, accessing from 17-21
 - keycodes 17-22
 - keymap 17-24 to 17-35
 - LEDs 17-21
 - legends 17-22
 - Setup key combination 17-21
- VT320 terminal emulation, *see* Terminal Emulator

W

- Wait for Broadcasts for (Change Setup Parameters) 9-30
- Wait for Keepalive Responses for (Change Setup Parameters) 9-30
- wd** command (Boot Monitor) 11-10
- What to do when XDM disconnects (Change Setup Parameters) 9-30
- What to do with XDMCP Broadcasts (Change Setup Parameters) 9-30
- What to do with XDMCP Indirects (Change Setup Parameters) 9-30
- White Pixel (Change Setup Parameters) 9-41
- wincen** command, diagnostic messages 18-127
- WINCEN messages 18-127
- WinCenter, configuration parameters for 9-40




wincenter-colors 9-40
wincenter-resources 9-40
 Window Delay Time (Change Setup Parameters) 9-29
 window managers
 Motif Window Manager, diagnostic messages 18-83
 NCD Window Manager
 diagnostic messages 18-133
 in session management files 8-9
 Window Size (Change Setup Parameters) 9-40
 Windows 95-compatible keyboard 17-13
 wireless
 configuration parameters for 9-32
 diagnostic messages 18-128
 statistics 10-28 to 10-29
 WIRELESS messages 18-128
 WM messages 18-133
wr command (Boot Monitor) 11-10
 Write Keyboard Description File (Change Setup Parameters) 9-24, 17-54
ws command (Boot Monitor) 11-10

X

X Access Control List (Change Setup Parameters) 9-9
 X extensions, disabling 9-40
 X resources, loading 8-7
 X server
 diagnostic messages 18-1
 directory
 default 4-2, 4-3
 non-standard 4-7, 4-14
 filename links 4-14
 filenames 4-2
 default 4-2
 disabling filenames 4-5
 non-standard 4-7
 location of 4-7, 4-12, 4-13

X server (continued)
 modules
 configuration parameters for 9-29
 load policy 4-10 to 4-12
 loading, diagnostic messages 18-103
 statistics 10-8
 protocols for loading 4-1
 screen resolution reported by 9-54
 version, displaying 16-8
 see also booting
 X session
 restarting with SNMP 16-10
 see also XDM (X Display Manager)
 X Session (Change Quick Setup) 9-6
 X settings, retaining 9-40
Xaccess file 8-11 to 8-13
XAUTHORITY environment variable 8-16
 XDM Authentication Key (Change Setup Parameters) 9-9
 XDM (X Display Manager)
 access control 8-15 to 8-16
 components of 8-4
 configuration files 8-6 to 8-14
 configuration parameters for 9-6, 9-29
 defaults 8-2
 defined 8-3
 diagnostic messages 18-78
 disconnecting, terminal actions 8-17
 DISPLAY variable automatically set 8-5
 error message log 8-14
 hosts
 configuring 8-5 to 8-15
 controlling access to 8-11 to 8-13
 keepalives 8-18 to 8-19
 login banner
 configuring 8-14
 delay before displaying 8-17
 Login Chooser, redisplay of 8-17
 MIT-MAGIC-COOKIE-1 8-16
 OpenWindows environment 8-14, 8-15

- XDM (X Display Manager) (continued)
 - polling interval, configuring 8-14
 - queries, types of 8-4
 - resources
 - loading from session management files 8-7
 - login box 8-14
 - xdm** program 8-13
 - userAuthDir** resource 8-16
- X session
 - ending 8-17
 - session management files, system-wide 8-7 to 8-11
- X11R3 version 8-19
- Xaccess** file 8-11 to 8-13
- .Xauthority** file 8-16
- XAUTHORITY** environment variable 8-16
- xdm** daemon
 - configuring 8-13 to 8-14
 - starting 8-15
- XDM-AUTHORIZATION-1 8-16
- xdm-config** file 8-13 to 8-14, 8-16
- XDMCP, defined 8-4
- xdm-errors** file 8-14
- xrdb(1)** 8-14
- Xreset** file 8-7
- Xresources** file 8-14
- Xservers** file 8-19
- .xsession** file 8-7
- Xsession** file
 - configuring 8-7 to 8-11
 - for NCD local window manager 8-9
 - for OpenWindows 8-10
- Xstartup** file 8-7
- xdm** (XDM daemon) 8-6, 8-13 to 8-14
- XDM Display Class (Change Setup Parameters) 9-29
- XDM Manufacturer Display ID (Change Setup Parameters) 9-29
- xdm-config** file 8-13 to 8-14, 8-16
- xdm-errors** file 8-14
- xfd(1)** 7-18
- xfontsel(1)** 7-19
- XKeysymDB** file 5-15
- XLFD (X Logical Font Description) 7-2, 7-19
- xlsfonts(1)** 7-18
- xrdb(1)**
 - OpenWindows version 8-14
 - X resources, loading 8-7
- XRemote
 - configuration parameters for 9-6, 9-41
 - diagnostic messages 18-136, 18-138
 - statistics 10-30 to 10-31
- XREMOTE messages 18-136
- XRemote Session (Change Quick Setup) 9-6
- xremote-additional-escape-chars** 9-41
- xremote-authorize-xremote-clients** 9-41
- xremote-data-compression-mode** 9-41
- xremote-next-receive-sequence-number** 10-31
- xremote-next-transmit-sequence-number** 10-31
- xremote-oldest-unacknowledged-packet** 10-31
- xremote-packet-round-trip-time** 10-30
- xremote-packets-received** 10-30
- xremote-packets-received-out-of-sequence** 10-30
- xremote-packets-retransmitted** 10-30
- xremote-packets-transmitted** 10-30
- xremote-packets-with-errors-received** 10-30
- xremote-packet-transmission-errors** 10-30
- xremote-receive-window-size** 10-31
- xremote-state** 10-30
- xremote-tcp-port** 9-41
- xremote-time-out-length** 10-30
- xremote-transmit-window-size** 10-30
- xremote-xremotetcp-connections** 9-41
- xremote-xremote-version** 10-30
- Xreset** file 8-7



Xresources file 8-14
XRPRINTD messages 18-138
XSERVER messages 18-139
xserver-access-control-enabled 9-9
xserver-access-control-enabled-default 9-9
xserver-access-control-list 9-9
xserver-arc-cache-max-size 9-40
xserver-black-pixel 9-41
xserver-default-colormap 9-41
xserver-default-font 7-13, 9-23
xserver-default-font-path 9-4, 9-23
xserver-default-visual 9-41
xserver-disabled-extensions 9-40
xserver-enable-local-dead-key-processing 9-25
xserver-enable-local-lightpen-blue-flood 9-25
xserver-font-alias-file-name 9-23
xserver-font-cache-max-size 7-14, 9-23
xserver-font-directory-file-name 9-23
xserver-font-path-alias-table 9-24
xserver-fontserver-open-timeout 7-25, 9-24
xserver-fontserver-read-timeout 7-26, 9-24
xserver-fontserver-reopen-timeout 7-25, 9-24
xserver-fontserver-retry-attempts 7-26, 9-24
xserver-input-extension-device 9-25, 15-3, 15-4
xserver-keyboard-description-file 9-24
xserver-keyboard-narrow-keysym-tables 9-24
xserver-keyboard-type 9-24
xserver-keysym-file 2-5, 9-40
xserver-mouse-buttons 9-25
xserver-retain-font-path 9-23
xserver-retain-x-settings 9-40
xserver-rgb-file 2-5, 9-40
Xservers file 8-7, 8-19
xserver-touchscreen-calibration limits 9-25
xserver-white-pixel 9-41
.xsession file 8-6, 8-7
Xsession file 8-6

xset(1)
 displaying the font path 7-18
 modifying current font path 7-13
Xstartup file 8-6
XT messages 18-141

Z

zk command (Boot Monitor) 11-10
zs command (Boot Monitor) 11-10

